

6 PIECES--
ASSEMBLE SIDES TO THE TOP AND BOTTOM
SCREW TOGETHER
WITH THE PROVIDED # 6 1+5/8 DRYWALL SCREWS
TABS GO UP AND TOWARDS THE BACK
IF INSTALLING LIGHTS, HEAT ,ETC
PULL THE PLUGS THROUGH THE LIGHT HOLES
AT THE TOP OF THE BACK
THEN PUT THE FRONT AND BACK ON, SCREW THEM DOWN
SILICONE THE INSIDE 4 EDGES OF THE FLOOR

